



## **Important Notice / Notas Importante**

### **Fan Motor Operation after Cooking**

After using the oven, the fan may continue to operate to cool the electric components and “COOLING” appears in the display window. You can take out the food from the oven while the fan operates. It is recommended to keep the oven plugged in until the Fan Motor completely stops operating.

### **Operación del Motor del Ventilador después de Cocinar**

Después de usar el horno, el ventilador puede continuar funcionando para enfriar los componentes eléctricos y aparecerá "ENFRIANDO" en la pantalla. Puede sacar la comida del horno mientras el ventilador funciona. Se recomienda mantener el horno enchufado hasta que el motor del ventilador deje de funcionar completamente.

### **Smoke and Burnt smell may occur after the first use.**

This is not a malfunction and will go away after a few uses.

### **Puede haber humo y olor a quemado después del primer uso.**

Esto no es un mal funcionamiento y desaparecerá después de algunos usos.