

Panasonic®

Model No. **KX-TG5431**

Model No. **KX-TG5432**


Model No. **KX-TG5433**

Quick Guide


Please read the operating instructions for further details.

Connections

Base unit



Charger unit (KX-TG5432 and KX-TG5433 only)





Note:

- Base unit: Use only the included Panasonic AC adaptor PQLV1.
- Charger unit: Use only the included Panasonic AC adaptor KX-TCA1.
- Make sure that the AC adaptor and telephone line cords are plugged into the unit properly.
- The AC adaptor must remain connected at all times. (It is normal for the adaptor to feel warm during use.)

PQQW13514ZA DM1104PY0

Battery installation


- 1 Insert the battery (①), and press it down until it snaps into the compartment (②).
- 2 Close the handset cover.




Battery charge

Place the handset on the base unit or charger for **6 hours** before initial use.

Base unit




Charger unit (KX-TG5432 and KX-TG5433 only)




Navigator key

The handset navigator key can be used to navigate through menus and to select items shown on the display, by pressing [▲], [▼], [←], or [→].



Soft keys

The handset features 2 soft keys. By pressing a soft key, you can select the function displayed directly above it.



Setting the date and time

Set the date and time so that the unit will announce the day and time each message was recorded by the answering system when you play back messages.

- 1 Press **[MENU]**.
- 2 Press **[4]**.
- 3 Enter the current month, day, and year by selecting 2 digits for each.
Example: June 15, 2005
Press **[0][6] [1][5] [0][5]**.
- 4 Enter the current hour and minute (12-hour clock format) by selecting 2 digits for each.
Example: 9:30 PM
Press **[0][9] [3][0]**.

```
Date: 12. 31. 2005
Time: 12: 00 AM
↓AM/PM      Save↓
```

```
Date: 06. 15. 2005
Time: 12: 00 AM
↓AM/PM      Save↓
```


- 5 Select "AM" or "PM" by pressing **[AM/PM]**.

```
Date: 06. 15. 2005
Time: 09: 30 AM
↓AM/PM      Save↓
```

- 6 Press **[Save]**, then press **[OFF]**.






Recording your greeting message

You can record your own greeting message (max. 2 minutes) that will be played when the answering system answers a call. If you do not record a greeting message, a pre-recorded greeting message will be used.



- 1 Press **[GREETING REC]**.
 - The unit announces "To record greeting, press record again."
- 2 Within 10 seconds, press **[GREETING REC]** again.
- 3 After the unit beeps, speak clearly about 20 cm (8 inches) away from the MIC.
- 4 To stop recording, press **[GREETING REC]** or **[STOP]**.

To play back the greeting message
Press **[GREETING CHECK]**.

Basic operation	
Feature	Operation
To make a call	Press [], then dial the phone number.
To turn on the speakerphone	Press [].
To hang up	Press [OFF] .
To adjust the receiver or speaker volume	While using the receiver or speaker, press [v] or [▲] repeatedly.
To redial the last number dialed	Press [], then press [REDIAL] .
To make a call using the redial list	Press [REDIAL] . Scroll to the desired number by pressing [v] or [▲] . Then, press [].
To answer a call	Press [].
To put an outside call on hold	KX-TG5431: Press [HOLD] during an outside call. KX-TG5432 and KX-TG5433: Press [HOLD] 2 times during an outside call.

Answering system	
Feature	Operation
To turn the answering system on/off	Press [ANSWER ON] .
To listen to new messages	When the MESSAGE indicator FLASHES on the base unit, press [MESSAGE] .
To listen to old messages	When the MESSAGE indicator DOES NOT FLASH, press [MESSAGE] .
To erase a message	Press [ERASE] while the message is being played.
To erase all messages	Press [ERASE] 2 times while the base unit is not in use.

Phonebook


Adding items to the phonebook

1 Press **[Phonebook]**.




2 Press **[Add]**.

Example:




3 Enter the name (max. 16 characters).




4 Press **[Next]**.

5 Enter the phone number (max. 32 digits).



6 Press **[Next]**.

Example:



7 Press **[Save]**.

- To add other items, repeat from step 2.

8 Press **[OFF]**.

Calling someone in the phonebook

1 Press **[Phonebook]**.

2 Press **[v]** or **[^]** repeatedly to display the desired item.

- To exit the phonebook, press **[OFF]**.

3 Press **[↶]** or **[↷]**.

Caller list


Viewing the caller list and calling back

1 Press **[v]** or **[^]** to enter the caller list.

2 Press **[v]** to search from the most recent call, or press **[^]** to search from the oldest call.

- The caller's name and phone number are displayed alternately.

Example:



- To exit the caller list, press **[OFF]**.

3 Press **[↶]** or **[↷]**.

Displayed symbols

- If the same caller calls more than once, it will be displayed with the number ("x2" to "x9"). Only the date and time of the most recent call will be stored.
- A ✓ is displayed next to items which have already been viewed or answered on this handset.

Programming via direct commands

You can program most features using “direct commands”—special codes that take you directly to the feature you wish to program and allow you to select the desired setting. There is no need to scroll through the unit’s menus.

- 1** Press **[MENU]**.
- 2** Enter the desired feature code (shown below).
- 3** Enter the desired setting code (shown below).
- 4** Press **[Save]**.
- 5** Press **[OFF]** to exit programming mode.

Direct commands chart

Feature	Feature code	Setting code
Ringer volume	[1] [1]	[1] : Low [2] : Medium [3] : High [0] : Off
Ringer tone	[1] [2]	[1]–[3] : Tone pattern 1–3 [4]–[7] : Melody pattern 1–4
Voice enhancer	[5]	[1] : On [0] : Off
LCD contrast	[0] [1]	[1]–[6] : Level 1–6
Auto talk	[0] [3]	[1] : On [0] : Off
Set dial mode	[0] [5] [1]	[1] : Pulse [2] : Tone
Ring count	[0] [6] [1]	[2]–[7] : 2–7 rings [0] : Toll saver
Recording time	[0] [6] [2]	[1] : 1 minute [2] : 2 minutes [3] : 3 minutes [0] : Greeting only
Change language	[0] [8]	[1] : English [2] : Spanish
Message alert	[0] [†]	[1] : On [0] : Off

Important information about subscription services

In order to use Caller ID, Call Waiting, or Call Waiting Caller ID (CWID), you must first contact your telephone company and subscribe to the desired service.

- For more information, contact your telephone company.

If the Call Waiting Caller ID (CWID) feature does not function:

- You may need to contact your telephone company to activate this specific service, even if you already subscribed to both Caller ID and Call Waiting with Caller ID services (CWID).

If you subscribe to a flat-rate bundle service that includes Caller ID, Call Waiting, Voice Mail, and unlimited local/regional/long distance calls, please read the following:

- To use the Voice Mail service provided by the telephone company rather than the unit's answering system, turn off the answering system by pressing **[ANSWER ON]** on the base unit.

This unit does not have an indicator to indicate if there are new messages in your mailbox service.

- To use this unit's answering system rather than the Voice Mail service provided by your telephone company, please contact your telephone company to deactivate your Voice Mail service.

If the telephone company cannot do this, set this unit's "Ring count" setting so that this unit's answering system answers calls before the telephone company's Voice Mail service tries to answer your calls. It is necessary to check the ring count required to activate the Voice Mail service provided by your telephone company before changing this setting.

Example: To set the ring count to "2", press **[MENU] [0] [6] [1]**. When "Ring count" is displayed, press **[2] [Save]**.

IMPORTANT!

**If your product is not
working properly. . .**

- 1 Read this Quick Guide or Operating Instructions**
- 2 Visit our website:
<http://www.panasonic.com/consumersupport>**
- 3 Contact us via the web at:
<http://www.panasonic.com/contactinfo>**
- 4 Call us at: 1-800-211-PANA (7262)**

To order a replacement batteries,
1-800-332-5368
<http://www.panasonic.com/batterystore>